



UG87-Out LoRaWAN Gateway

Quick Start Guide



Welcome

Thank you for choosing Ursalink UG87 LoRaWAN Gateway.

This guide teaches you how to install the UG87 (Outdoor) and how to log in the web GUI to configure the device. Once you complete the installation, refer to the Ursalink UG87 User Guide for instructions on how to perform configurations on the device.

Related Documents


This Quick Start Guide only explains the installation of Ursalink UG87 LoRaWAN Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
Ursalink UG87 Datasheet	Datasheet for the Ursalink UG87 LoRaWAN Gateway.
Ursalink UG87 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Ursalink website: <http://www.ursalink.com>.

Declaration of Conformity

UG87 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
Ursalink technical support:
Email: support@ursalink.com
Tel: 86-592-5023060
Fax: 86-592-5023065


1. Packing List

Before you begin to install the UG87 LoRaWAN Gateway, please check the package contents to verify that you have received the items below.


1.1 Package Contents



1 × UG87



1 × Ethernet Extension Cord



1 × Water-proof Connector



1 × Power Supply Cable




2 × Cellular Antennas




1 × LoRa Antenna




1 × GPS Antenna




1 × Warranty Card



1 × Quick Start Guide



1 × Wall Mounting Kit




2 × Pole Mounting Kit




Screws


Optional Accessories




+



1 × Pole Mount A + 2 × U-Bolt



+



1 × Pole Mount B + 2 × U-Bolt




Screws


Required Additional Equipment





1 × Personal Computer



1 × Ethernet Cable



1 × Wrench M6



2 × Screwdrivers


(Phillips-head and Flathead)




If any of the above items is missing or damaged, please contact your Ursalink sales representative.

2. Hardware Introduction


2.1 Overview




Top View



Bottom View




Front & Rear View



Core plug—seal up these unneeded interfaces.

Ethernet Interface




Power Interface




Vent plug—applied to balance different pressure, protect UG87 from dust and water, and ventilate the enclosure.

Antenna Interface

2.2 Dimensions (mm)



2.3 LED Indicators

 LED indicators are on the front panel of device.

LED	Indication	Status	Description	
POWER	Power Status	On	The power is switched on	
		Off	The power is switched off	
STATUS	System Status	Green Light	Static: Start-up Blinking slowly: the system is running properly	
		Off	The system goes wrong	
LoRa	LoRa Status	Green Light	Packet Forwarder mode is running well.	
		Off	Packet Forwarder mode is running off.	
VPN	VPN Status	Green Light	VPN is connected	
		Off	VPN is disconnected	
SIM1/SIM2	SIM Card Status	Off	SIM1 or SIM2 is registering or fails to register (or there are no SIM cards inserted)	
		Green Light	Blinking slowly: SIM1 or SIM2 has been registered and is ready for dial-up	
			Blinking rapidly: SIM1 or SIM2 has been registered and is dialing up now	
Signal Strength	Signal 1/2/3	Green Light	Static: SIM1 or SIM2 has been registered and dialed up successfully	
			Off	No signal
			Static/Off/Off: weak signals with 1-10 ASU (please check if the antenna is installed correctly, or move the antenna to a suitable location to get better signal)	
			Static/Static/Off: normal signals with 11-20 ASU (average signal strength)	
			Static/Static/Static: strong signals with 21-31 ASU (signal is good)	

2.5 Reset Button

 Reset button is on the front panel of device.

Function	Description	
	STATUS LED	Action
Reboot	Blinking	Press and hold the reset button for about 5-15 seconds.
	Static Green	Release the button and wait for system to reboot.
Reset	Blinking	Press and hold the reset button for more than 15 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Blinking	The gateway is now reset to factory default.

2.6 Ethernet Port Indicator

 Ethernet port indicators are on the front panel of device.

Indicator	Status	Description
Link Indicator (Orange)	On	Connected
	Blinking	Transmitting data
	Off	Disconnected
Rate Indicator (Green)	On	1000 Mbps mode
	Off	100 Mbps mode

3. Hardware Installation

Environmental Requirements


- Power Input: 100-240VAC (Option: 9-48 VDC)
- Power Consumption: Typical 3.3W (Max 6.4 W)
- Ingress Protection: IP67
- Operating Temperature: -40°C to 70°C (-40°F -158°F)
- Relative Humidity: 0% to 95% (non-condensing) at 25°C/77°F

3.1 SIM Card Installation

3.1.1 Remove the detachable cover

Remove the detachable cover of the housing with a screwdriver (M4).


Note: Your device has been installed into the enclosure before delivery.



3.1.2 SIM Card Installation

A. Push the yellow button on the left panel of the slot, and then you will see the SIM card slot popping out directly.


B. Put SIM card onto the slot then insert the back into the hole.



3.2 Antenna Installation

3.2.1 Remove the protective caps


Remove the protective caps from the antenna connectors. Take cellular connector as an example.



3.2.2 Connect the antenna

Connect the antenna to the corresponding antenna connector by holding on the metal part of the antenna and rotating it clockwise.


Note: Each antenna is labeled as 3G, 4G or LoRa.



3.3 Power Connection



3.3.1 Remove the protective caps

Locate the power port marked POWER on the left side of the enclosure and remove the protective cap to find the connection pins.




3.3.2 Connect the power cable

Connect a power supply cable to the power port, and rotate it clockwise.




PIN	Color	Description
1	Brown	L (VIN+)
2	Black	GND
3	Blue	N (VIN-)

3.4 Ethernet Connection



1. Get the network cable through the screw nut, rubber ring and the screw bolt;
2. Insert the rubber ring into the screw bolt;
3. Connect the screw nut to the screw bolt;
4. Place the O-Ring on the network port connector;
5. Connect the RJ45 to the Network port connector, and tighten the screw bolt and the connector.

3.5 Connect UG87 to a Computer




3.6 Mount Gateway

The gateway can be mounted to a wall or a pole.

3.6.1 Wall Mounting

Make sure you have mounting bracket, bracket mounting screws, wall plugs, wall mounting screws and other required tools.

1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.




3. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

Note: The connecting lines of adjacent points are at right angles.

4. Drill the four holes with a depth of 32 mm by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.
5. Insert four wall plugs into the holes respectively.
6. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.

Note: Place the power port on the button when installing.




7. Reconnect the cables.


3.6.2 Pole Mounting (Hose clamp)

Make sure you have mounting bracket, bracket mounting screws, hose clamp and other required tools.

1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.




3. Loosen the hose clamp by turning the locking mechanism counter-clockwise.



4. Straighten out the hose clamp and slide it through the rectangular holes in the mounting bracket, wrap the hose clamp around the pole.

5. Use a screwdriver to tighten the locking mechanism by turning it clockwise.




6. Reconnect the cables.

3.6.3 Pole Mounting (U-bolt)


Note: Pole mounting (U-bolt) is optional.

Make sure you have mounting bracket, bracket mounting screws, hose clamp and other required tools.

1. Before you start, make sure your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.



3. Wrap the U-bolt around the pole and mount the bracket with the mounting screws.





4. Reconnect the cables.

Getting Started


4. PC Configuration for UG87 Web GUI

Please connect PC to GE port of UG87 directly. PC can obtain an IP address, or you can configure a static IP address manually. The following steps are based on Windows 10 operating system for your reference.




① Click “Search Box” to search “Control Panel” on the Windows 10 taskbar.


② Click “Control Panel” to open it, and then click “View network status and tasks”.




③ Click “Ethernet” (May have different names).




④ Click “Properties”.



⑤ Double Click “Internet Protocol Version 4 (TCP/IPv4)” to configure IP address and DNS server.



⑥ Method 1: click “Obtain an IP address automatically”;



Method 2: click “Use the following IP address” to assign a static IP manually within the same subnet of the gateway.

(Note: Remember to click “OK” to finish configuration.)

5. Access to UG87 Web GUI for Cellular Connection

This chapter explains how to log in UG87 Web GUI, and connect the gateway to cellular network. Ursalink UG87 provides web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:

IP Address: **192.168.1.1**


Username: **admin**

Password: **password**

5.1 Log in the Gateway


! Make sure your PC is connected to the same network as shown in [Section 4](#).

- A. Start a Web browser on your PC (Chrome and IE are recommended), type in the IP address, and press Enter on your keyboard.
- B. Enter the username and password, click “Login”.




! If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

C. When you log in with the default username and password, you will be asked to modify the password. It’s suggested that you change the password for the sake of security. Click “Cancel” button if you want to modify it later.




D. After you log in the Web GUI, you can view system information and perform configuration on the gateway.




5.2 Configure the Cellular Connection

Take inserting SIM card into SIM1 slot as an example; please refer to the following detailed operations.

- Click "Network" → "Interface" → "Cellular" → "Cellular Setting" to configure the cellular info.
- Enable SIM1.
- Choose relevant network type. "Auto", "4G First", "4G Only", "3G First", "3G Only", "2G First" and "2G Only" are optional.
- Click "Save" and "Apply" for configuration to take effect.





If you select “Auto”, the gateway will obtain ISP information from SIM card to set APN, Username, and Password automatically. This option will take effect when the SIM card is issued from a well-known ISP. If you select “4G First” or “4G Only”, you can click “Save” to complete the configuration directly. If you select “3G First”, “3G Only”, “2G First” or “2G Only”, you should manually configure APN, Username, Password, and Access Number.


UG87 have two cellular interfaces, named SIM1 & SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, SIM1 interface takes precedence by default.

5.3 Check the Cellular Connection Status

5.3.1 Check the Cellular Connection Status by Web GUI of Gateway

Click “Status” → “Cellular” to view the status of the cellular connection. If it shows “Connected”, it means

SIM1 has dialed up successfully.



The screenshot shows the URSALINK web interface with the 'Cellular' tab selected. The interface is divided into a left sidebar and a main content area. The sidebar contains menu items: Status, LoRaWAN, Network, System, Industrial, Maintenance, and APP. The main content area is titled 'Cellular' and is divided into two sections: 'Modem' and 'Network'. The 'Modem' section lists various parameters such as Status (Ready), Model (EC25), Current SIM (SIM1), Signal Level (31asu (-51dBm)), Register Status (Registered (Home network)), IMEI (861107032321490), IMSI (460110269496240), ICCID (89860317245923922835), ISP (CHN-CT), Network Type (LTE), PLMN ID (46011), LAC (5f02), and Cell ID (5fb0d34). The 'Network' section lists Status (Connected), IP Address (172.21.143.187), Netmask (255.255.255.248), Gateway (172.21.143.188), DNS (218.85.152.99), and Connection Duration (0 days, 00:01:39). A callout box highlights the 'Connected' status in the Network section.

Status	Overview	LoRa	Cellular	Network	VPN
LoRaWAN	Modem				
Network	Status		Ready		
System	Model		EC25		
Industrial	Current SIM		SIM1		
Maintenance	Signal Level		31asu (-51dBm)		
APP	Register Status		Registered (Home network)		
	IMEI		861107032321490		
	IMSI		460110269496240		
	ICCID		89860317245923922835		
	ISP		CHN-CT		
	Network Type		LTE		
	PLMN ID		46011		
	LAC		5f02		
	Cell ID		5fb0d34		
	Network				
	Status		Connected		
	IP Address		172.21.143.187		
	Netmask		255.255.255.248		
	Gateway		172.21.143.188		
	DNS		218.85.152.99		
	Connection Duration		0 days, 00:01:39		

5.3.2 Check the Cellular Connection Status by Hardware

On the other hand, you can check the status of SIM1 indicator. If it keeps on green light statically, it means SIM1 has dialed up successfully.

5.4 Check if Network Works Properly by Browser on PC

Open your preferred browser on PC, then type any available web address into address bar and see if it is able to visit Internet via UG87.

6. Packet Forwarder Testing

6.1 Node Parameters

Channel Plan	AS923
Frequency	923.4MHZ, 923.2MHZ
Join Type	OTAA
Device EUI	60C5A8FFFE0003F9
Application EUI	70B3D57ED0007AC2
App Key	328F2A3F5BA8D0B236459CF06D0512B5

6.2 Configure The Things Network

A. Gateway Configuration

Gateway EUI	24E124FFFEF0132E
Frequency Plan	Asia 920-923MHZ
Server ID	Switch-router (ttn.opennetworkinfrastructure.org)

GATEWAY SETTINGS

- General
- Owner
- Location
- Privacy
- Information
- Collaborators

GENERAL

Description
A human-readable description of the gateway.
USRALINK

Frequency Plan
The frequency plan this gateway will use.
Asia 920-923MHz

Router
The id of the router your gateway will connect to.
switch-router

Automatically update gateway
If enabled the gateway will periodically check if updates are available and perform them.
Enabling auto updates may cause your gateway to have unexpected downtime when updating.


Beta Updates
Turn this on to receive firmware from the beta release channel.

B. Applications Configuration

APPLICATIONS


add application

123454321	USRALINK	switch-handler	70B3D57ED0007AC2
-----------	----------	----------------	------------------



6.3 Packet Forwarder Configuration

A. Click “LoRaWAN” → “Packet Forwarder” → “General” to configure the general setting.



B. Click “Radios” to configure the center frequency and channels.

General **Radios** Advanced Custom Traffic

Radio Channel Setting

Supported Frequency: AS923

Name	Center Frequency/MHz
Radio 0	923.6
Radio 1	922.6

Multi Channels Setting

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	923.2
<input checked="" type="checkbox"/>	1	Radio 0	923.4
<input checked="" type="checkbox"/>	2	Radio 0	923.6
<input checked="" type="checkbox"/>	3	Radio 1	922.2
<input checked="" type="checkbox"/>	4	Radio 1	922.4
<input checked="" type="checkbox"/>	5	Radio 1	922.6
<input checked="" type="checkbox"/>	6	Radio 1	922.8
<input checked="" type="checkbox"/>	7	Radio 1	923.0

C. Click "Traffic" to view the data communication of UG87

General Radios Advanced Custom **Traffic**

Traffic Setting

Stop Clear



Rfch	Direction	Time	Ticks	Frequency	Datarate	Coderate	RSSI	SNR
1	up	-	2422567628	922.6	SF7BW125	4/7	-86	-11.5
1	up	-	2027425380	923.0	SF7BW125	4/6	-87	-10.8
1	up	-	1906152459	922.2	SF7BW125	OFF	-89	-11.8
0	up	-	1896642603	923.6	SF7BW125	4/6	-89	-12.0
0	up	-	1833066556	923.8	SF7BW250	4/5	-86	-12.0
0	up	-	1793222443	923.4	SF7BW125	4/8	-85	-11.2
0	up	-	1768923067	923.2	SF7BW125	4/5	-89	-11.8
1	up	-	1736475188	922.8	SF8BW125	4/8	-86	-14.0
1	up	-	1504937860	923.0	SF7BW125	4/5	-87	-11.5

6.4 Check Data Transmission on The Things Network

A. Click "Gateways", you can check the Gateways status.



B. Click “Applications” and select the Applications, then go to “Data”, you can find the data from the Node.



7. Network Server Testing

Note that only gateway with activated built-in Network Server supports this function.

7.1 Node Parameters

Channel Plan	AS923
Frequency	923.4MHZ, 923.2MHZ
Join Type	OTAA
Device EUI	60C5A8FFFE0003F9
Application EUI	70B3D57ED0007AC2
App Key	1A98A25536993A882154B81551F18A76

7.2 Network Server Configuration

A. Click “LoRaWAN” → “Network Server” → “General” to configure the general setting.

Note that the channel plan of the nodes and network server need to be the same.

The screenshot shows the 'General Setting' page for the Network Server. The left sidebar contains navigation options: Status, LoRaWAN, Packet Forwarder, Network Server (selected), Network, System, Industrial, Maintenance, and APP. The main content area has tabs for General, Applications, Profiles, Device, and Packets. Under 'General Setting', the 'Enable' checkbox is checked. The 'Mode' is set to 'Network Server'. The 'NetID' is '010203'. 'Join Delay' is '5 sec', 'RX1 Delay' is '1 sec', and 'Lease Time' is '744-0-0 hh-mm-ss'. The 'Log Level' is 'info'. Under 'Channel Plan Setting', the 'Channel Plan' is 'AS923'. Below this is a table for 'Additional Channels' with columns: Frequency(MHz), Min Datarate, Max Datarate, and Operation. A '+' button is at the bottom right of the table.

B. Add a new Application

The screenshot shows the 'Applications' page. The left sidebar is the same as in the previous screenshot. The main content area has tabs for General, Applications (selected), Profiles, Device, and Packets. Under 'Applications', there is a table with columns: ID, Name, Description, Payload Codec, and Operation. A '+' button is at the bottom right of the table.

General **Applications** Profiles Device Packets

Applications

Name:

Description:

Payload Codec:

General **Applications** Profiles Device Packets

Applications

ID	Name	Description	Payload Codec	Operation
8	Smoke-Sensor-APP	Smoke Sensor	None	<input type="button" value="edit"/> <input type="button" value="delete"/>
<input type="button" value="add"/>				

C. Add Profiles for the device

General Applications **Profiles** Device Packets

Device Profiles

Name	Max TXPower	Join Type	Class Type	Operation
<input type="button" value="add"/>				

General Applications **Profiles** Device Packets

Device Profiles




Name:

Max TXPower:

Join Type:




Class Type:

Advanced:

General	Applications	Profiles	Device	Packets
Device Profiles				
Name	Max TXPower	Join Type	Class Type	Operation
Smoke-Sensor	0	OTAA	Class A	 
				

D. Add device

General	Applications	Profiles	Device	Packets
Device				
General				
Device Name	<input type="text" value="Somke-Sensor"/>			
Description	<input type="text" value="Somke Sensor"/>			
Device EUI	<input type="text" value="60C5A8FFFE0003F9"/>			
Device-Profile	Smoke-Sensor ▼			
Application	▼			
Frame-counter Validation	<input checked="" type="checkbox"/>			
Activate Device(OTAA)				
Application Key	<input type="text" value="1A98A25536993A882154B815!"/>			
Device Address	<input type="text"/>			
Network Session Key	<input type="text"/>			
Application Session Key	<input type="text"/>			
Uplink Frame-counter	<input type="text" value="0"/>			
Downlink Frame-counter	<input type="text" value="0"/>			
<input type="button" value="Save"/>		<input type="button" value="Cancel"/>		

General	Applications	Profiles	Device	Packets		
Device						
Device Name	Device EUI	Device-Profile	Application	Last Seen	Actived	Operation
Somke-Sensor	60c5a8ffe0003f9	Smoke-Sensor	Smoke-Sensor-APP	---	---	 
						

7.3 Package Forwarder Configuration

Click “LoRaWAN” → “Packet Forwarder” → “Radios” to configure the center frequency and channels

Note that node frequency needs to be included in the channels frequency.

The screenshot shows the 'Radio Channel Setting' configuration page. The 'Supported Frequency' is set to 'AS923'. Below, there are two tables: 'Radio Channel Setting' and 'Multi Channels Setting'.

Name	Center Frequency/MHz
Radio 0	923.6
Radio 1	922.6

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	923.2
<input checked="" type="checkbox"/>	1	Radio 0	923.4
<input checked="" type="checkbox"/>	2	Radio 0	923.6
<input checked="" type="checkbox"/>	3	Radio 1	922.2
<input checked="" type="checkbox"/>	4	Radio 1	922.4
<input checked="" type="checkbox"/>	5	Radio 1	922.6
<input checked="" type="checkbox"/>	6	Radio 1	922.8
<input checked="" type="checkbox"/>	7	Radio 1	923.0

7.4 Check the Packets

Click “LoRaWAN” → “Network Server” → “Packets” to check the packets from the node on network server.

The screenshot shows the 'Network Server' configuration page with the 'Packets' tab selected. It displays a table of received packets with the following columns: Device EUI, Frequency, Datarate, SNR, RSSI, Size, Fcnt, Type, Time, and Details.

Device EUI	Frequency	Datarate	SNR	RSSI	Size	Fcnt	Type	Time	Details
60c5a8f1e0003f9	923200000	SF10BW125	12.8	-61	18	0	JnReq	2018-09-30T17:43:25+08:00	1
60c5a8f1e0003f9	923200000	SF10BW125	10.2	-63	18	0	JnReq	2018-09-30T17:42:48+08:00	1
60c5a8f1e0003f9	923200000	SF10BW125	11.5	-64	16	0	JnReq	2018-09-30T17:40:35+08:00	1
60c5a8f1e0003f9	923400000	SF10BW125	11.0	-60	16	0	JnReq	2018-09-30T17:36:08+08:00	1
60c5a8f1e0003f9	923200000	SF10BW125	11.5	-63	16	0	JnReq	2018-09-30T17:35:31+08:00	1
60c5a8f1e0003f9	923400000	SF10BW125	14.0	-38	16	0	JnReq	2018-09-30T17:34:54+08:00	1
60c5a8f1e0003f9	923400000	SF10BW125	11.0	-56	18	0	JnReq	2018-09-30T17:34:15+08:00	1
60c5a8f1e0003f9	923400000	SF10BW125	3.5	-62	18	0	JnReq	2018-09-30T17:33:38+08:00	1
60c5a8f1e0003f9	923400000	SF10BW125	11.0	-60	16	0	JnReq	2018-09-30T17:31:50+08:00	1

Showing 1 to 9 of 9 rows

[END]